

TYPICAL CONNECTION METHODS FOR SEWERS IN EASEMENTS (REAR OR SIDE BOUNDARIES)

INSPECTION OPENING (IO) INTERFACE METHOD

## **NOTES**

- 1. LOCATE SEWERS AND INSPECTION OPENINGS (IO'S) AS SHOWN IN DESIGN DRAWINGS.
- 2. "AS SPECIFIED" MEANS AS SPECIFIED BY THE WATER AGENCY.
- 3. RAISE IO TO SURFACE IN ACCORDANCE WITH WATER AGENCY REQUIREMENTS.

## **LEGEND**

INSPECTION OPENING (RAISED TO SURFACE)

SEALED BURIED CONNECTION POINT

FUTURE PROPERTY DRAIN

PROPERTY BOUNDARY

--- EASEMENT BOUNDARY

